assembly instructions

- 1. Print pages 2-4 and glue to board [e.g. foamboard 5 mm / $\frac{1}{4}$ inch thick].
- 2. Cut out pieces {a} to {e} and cut the marked slots into the width appropriate for type of board and jar.
- 3. Drop piece {a} into a sturdy transparent vessel with a minimum height of 22 cm / 8.5 inch and a top circumference between 4.5 and 5cm / 1 % and 2 inch [e.g. passata jar].
- 4. Assemble pieces {b} to {e} according to schematic.













